

Belair, in the Adelaide Hills, was one of the prettiest stations on the old SAR system, and the destination for visitors by rail to National Park. **Ross Hurley** takes us through the history of this popular station on the Main South Line.

Early History

Belair station was opened in 1883 with the opening of the Adelaide to Aldgate section of the Nairne line as a standard three-track crossing station with just a single stone platform. A wooden Class 2 ticket and telegraph office was provided on the Up platform. At the time morse telegraph was in use between Adelaide and Mount Barker. For the first three years all trains used this platform. Regular passenger services had commenced running as far as Aldgate in 1883.

During 1886 a wooden platform was erected for Down trains on the passing siding and the yard was interlocked for directional working. See the photo on the next page. The signal cabin was built in 1888.

In the 1890s a short wooden shelter, with enclosed ladies waiting room at one end, was built on the Up platform for the crowds that used the railway to visit the adjacent National Park. The shelter was extended in 1894 and 1909. Long Gully was another station providing transport to National Park, and from the late 1930s National Park station was opened, but metropolitan trains only stopped there for picnic traffic.

Newspaper reports in Trove provided much 'colour' on the history of Belair station. In 1895 a correspondent advocated a turntable be provided at Belair to avoid the necessity of engines going to Aldgate to turn. The Commissioner replied that such expenditure could not be justified (but the turntable was built about five years later). In 1908 the Railways Commissioner was requested to leave a few carriages at Belair on the most popular public holidays in order, so the correspondent said, that visitors could at least make sure of shelter and a degree of comfort whilst waiting to return to the city in the evening. These carriages might be timed to leave Belair by special engine about 7 pm, thus making patrons of the park independent of the ordinary trains which are usually so crowded from stations farther up the line that 'intending passengers at Belair are frequently compelled to wait on the platform for hours before being able to secure seats'. Also in 1908, a request was made for more shelter for the 'large number of passengers who are frequently compelled to stand on the platforms for an hour or two in all weathers waiting to return to the city in the evenings. The earlier trains on most of the holidays and at times on Saturdays...are so crowded before reaching Belair that a long wait is inevitable'. The tragic incident of a porter who died when trying to take the staff from the driver of a Down train in 1919 was also reported.

In 1899 the original wooden Down platform was rebuilt in stone further away from the Up platform to allow three tracks to run between the platforms. A new Down line was laid

Above. Belair station, c1915. Rx class engine 195 leads another Rx on an Up Melbourne Express while the carriages from a picnic train wait on the Through Main. Melbourne Express trains could stop at Belair to allow passengers from Victoria to alight. Photo: NRM Archives 2-71-a3283.



Modelling the Railways of South Australia - 2020

Previous page:

Above Left. This late 1890s photo of Belair station shows the wooden platform on the original Down line. The overbridge to National Park is clearly shown in the distance as well as the level crossing leading to Upper Sturt Road at the end of the platforms. On the Up platform are, from the left, the signal cabin which remained unaltered throughout the station's life, the original ticket and telegraph office and the short wooden shelter for the crowds who used the train to visit the nearby National Park. It incorporates a ladies waiting room at the far end. The shelter was later enlarged several times. Photo: Mitcham Local History Service P00080.

Below Left. Belair station c1910 showing the repositioned, stone Down platform, the Through Main running between the Up and Down Main lines and the extended waiting shed at its final length. The stone station office replacing the booking and telegraph office has yet to be built on the other side of the signal cabin. Photo: CA Petts, Mitcham Local History Service.

adjacent to the new Down platform. The goods line behind the Down platform was extended to service the goods siding and the 50 foot turntable which was installed at that time. The island Down platform was used to terminate picnic trains for National Park—all normal non-country passenger trains went through to Bridgewater or Aldgate. After passengers had alighted the picnic train would be stored on the old Down line.

The Railways Commissioners announced in the Adelaide newspapers, viewed on Trove, that excursion trains to Belair would commence running, on Saturdays, on 1 November 1893. The SAR advertisement of Picnic and Excursion trains to Belair in 1911, such as the one reproduced from the South Australian Fare and Time Tables book of that year, at right, would indicate that excursion trains operated from 1893 to at least 1911. Horse-drawn trolleys carried people into the park. The SAR Officers' Magazine reported that, in 1917, over 1300 people went to National Park by train. An extra train had to be put on in the evening to cater for the returning visitors. In the 1911 Working Time Table I can find a picnic train leaving Adelaide at 10 am for



Above. Half-plate glass negative of trains at Belair train station. The photo is dated c1910 but must be later than this as there are steps at the end of the Down platform and not on the c1910 photo on the previous page. A local passenger train stands on the far side of the Down platform while what appears to be a Melbourne Express passes through on the Down Main. Another local passenger, hauled by Rx 197, stands ready to depart from the Up platform. Photo: SLSA PRG 327/24.69.

Belair on Saturday mornings in the summer and a timetable path for the engine to return to Adelaide, but no path for the return of the train. Because it was downhill from Belair I presume the picnic train carriages were brought back to Adelaide by a regular Up country train.

A notice in Trove for 1921 advertises special excursion trains leaving the city at 1.45 pm to Belair and Long Gully on Sunday afternoons, returning from Long Gully at 7.30 pm.

A very short platform, called Nanawort Siding, was situated between Long Gully and Upper Sturt. Rail motors from Mount Pleasant used to stop there providing transport to Belair school for children living in the Upper Sturt area. The train also picked up school children from Aldgate and Bridgewater. The Belair public school, opened in 1912, was near Belair station at the time; it is now St Johns Grammar School.

Originally there was a level crossing from Sheoak Road across the tracks at the Mount Lofty end of the platforms, going behind the station and down the hill to Upper Sturt Road. This was the route for most people in the southern suburbs heading towards Murray Bridge and beyond. Visitors to the adjacent National Park also entered the Park from this road. By 1893 so many people were visiting National Park that

PICNIC EXCURSIONS, NATIONAL PARK, BELAIR.

- - (a) FROM ADELAIDE, GOODWOOD, MITCHAM—First class, ls.; second class, 8d.; Children under 14 years of age, half rates.

1911 South Australian Fare and Time Tables book.

1-1188 Belair 13m 51ch, 990ft

an overbridge direct into National park was built across the Mount Lofty end of the yard. The top photo on p1-1186 shows both the level crossing and the bridge. Both remained in use until 1914. A fatal accident in that year caused the level crossing to be closed and a second bridge at the Adelaide end of the yard to be built, as part of a re-aligned Upper Sturt Road. This bridge required substantial embankments and was made wide enough to cater for subsequent duplication to Belair.

Train Control between Adelaide and Murray Bridge was introduced in 1924. In communication with all signal cabins by selector telephone Train Control was then able to arrange the crossing of all trains to best advantage. This replaced the method of train working used up 'till then by signal staff who could only communicate with the cabin immediately in advance of or in arrears of their cabin.


Double track reached Belair in 1928. A new concrete station building replaced the wooden one. A brick toilet block, which still exists, was built behind where the old station building and telegraph office was. With duplication in 1928 the middle road became the Down Through Main for Up and Down traffic.


In 1933 a siding for railcars was



Above. The automatic electric upper quadrant Home signal at the Adelaide end of Belair, introduced in 1924, before duplication reached there in 1928. It governed the entrance to Belair yard through the Down Through Main and the back siding. The Upper Sturt Road overbridge is seen. Photo: Ron Stewien, NRM Archives.

Below. This 1951 photo shows Belair station in about its final form, showing the stone island Down platform, the middle Through Main and, on the Up platform, the stone station building, the signal cabin, the hedge which was planted where the old ticket office was and the platform shelter, now devoid of the enclosed ladies waiting room. A paleface 500 class Mountain Type is coming through on the Up Main on a freight train. Photo: SLSA B 58892/21.






Above. This c1930s photo shows the 50' turntable for turning Brill railcars and F class locos used in suburban service. In the late '30s the rails were extended over the pit wall to 53' in length. Photo: Coromandel Valley and District National Trust.

Inset: SAR lantern roof car used as gang bunkhouse on the end of the siding beside the turntable in 1940. Photo: Arnold Lockyer, NRMArchives 7-1074-b023-03. **Right**. Loco 701 with one of the two bogie refrigerated bulk milk vans leading the consist on its way through Belair. The bulk milk vans were used to transport milk from Murray Bridge to Adelaide. The old van used as a store sits on stumps between the turntable road and the Down Main. Photo: Arnold Lockyer collection, NRM Archives 7-1069-a097-10.



put in beside the turntable and an old sleeping van was placed on the siding as barracks. In 1937 the rails on the turntable were lengthened to 53 feet to accommodate diesel railcars.

In 1936 each Down road was provided with its own mechanical lower quadrant starting signal. The former starting signal was moved onto the post which originally carried the Up home and became the Advanced Starting signal. An upper quadrant electric Entering Block signal was placed at the start of the single line working to Long Gully. Barracks for railcar men were provided. In 1938 a 2000 gallon tank was erected on top of the cutting above the back road, piped to a standpipe beside the track. It was mainly used for watering F class engines at Belair but the 1942 WTT states, '...when necessary, engines working the Belair local service may replenish their water supply



at Belair...but the following instruction must be observed. When time is allowed in the time table, engines must take water at Blackwood'. The tank was removed in 1974.

In 1952 maintenance records say that the platforms were lengthened to

480 feet. Presumably it was the Mount Lofty end because the maintenance records say the siding was repositioned at the same time. The maintenance records report that the turntable was lengthened again in 1950 and removed entirely, with the siding, in 1977. *Left.* This photo shows the refreshment kiosk that served Park patrons for over 25 years at Belair. Photo: Coromandel Valley and District National Trust.

Left Middle. Model 75 Brill No.41 on an Up service arrives at Belair. The interesting mix of signals is evident; the lower quadrant Advanced Starter is on the left, followed by the upper quadrant Entering Block absolute signal just in front of the overbridge and then the Up Home upper quadrants on the other side of the bridge. The upper quadrant signals installed from Belair to Tailem Bend in late '20s and early' 30s essentially controlled the main line between stations under the direction of Train Control in Adelaide, with the assistance of signalmen. The lower quadrant 'mechanical' signals within yards were wholly under the control of the local signalmen. Photo: NRM Archives AK23442.

Left Below. In 1956 Model 75 Brill railcar 34 and Brill trailer 201 pause at Belair on an Up Bridgewater passenger. Photo: Douglas Colquhoun, NRM Archives 2-194-r-0210.

Below. Rear view of the starting signals at Belair. The taller left arm is the Down Through Main Starting and the shorter






Above. Mkado 702 hauls a freight through Belair probably in the 1950s. The lower quadrant bracket starting signals are on the left and the Advanced Starter, further back, is on the single, merged Down line just before it joins the single main line. The arch at the entrance to National Park is on the right. Photo: NRM Archives AK14562.



The Up Pinnaroo Express with its mixture of passenger cars behind at Belair Station, 5 May 1950. Photo: Friends of Belair Station.



Modelling the Railways of South Australia - 2020

Left. A local train, hauled by an F class, has arrived at Platform 3. It will be resupplied with water from the standpipe leading from a 2000 gallon tank on the embankment above.

Left Below. The engine has now uncoupled and, without turning on the turntable, is in the process of running around its train for the return journey. A pair of Model 75 Brills wait in the siding for later services. Both photos: Friends of Belair Station.

As part of the CTC installation in 1977 the Down Through road was removed and the Down terminating road extended to become part of the double line to Fosters Corner. Each track was signalled for bi-directional working with the new line becoming the passing siding. The goods siding and turntable were removed and colour light signalling installed, worked from a panel in the station office.

After its closure in 1977 the signal cabin was maintained as part of a railway history precinct by the local Friends of Belair Station. Some of the old signals and equipment have been re-erected behind the station. The current cabin is essentially what was there originally; it was completely rebuilt following an arson attack in 2003.

Train Control and Signalling

Initial safeworking on the South Line was Spagnoletti disc block, from 1890. This was replaced by Winters Block in 1894. Both these forms of safeworking used electricity to simply remind signalmen the location of trains by a needle on a dial. There was no interlocking of points and signals. In 1912 Winters Block was becoming discredited and electric staff was introduced between Mitcham and Mount Lofty.

In 1924 train control between Adelaide and Murray Bridge was introduced. Belair was resignalled at

Left. An F class being turned on the hand-operated turntable prior to running its return service. The turntable has been extended to 53' in length. Photo: Des Egan collection.



Above. Mountain 502 steams away from Adelaide with a load of Holden bodies from the GMH factory at Woodville, c1950s. The Advanced Starter is no longer there. Photo: NRM Archives AK23419.

Right. Red Hens stand at the Up and Down platforms while a three-car Bluebird set rolls through Belair prior to the Through Main being removed in 1977. Photo: NRM Archives AK23414.

Right Below. A Red Hen set stands in the Up platform ready for its return service to Adelaide. The Through Main has been removed. Photo: NRMArchives AK12679.

this time with some upper quadrant signals installed. In 1925 electric staff was abolished and upper quadrant signals were introduced between Blackwood and Mount Lofty. Upper quadrant signals were progressively introduced to Belair over the period 1924 to 1934.

In 1928 double line automatic signalling between Blackwood and





Belair was introduced with the opening of the duplication.

CTC and colour light signalling between Belair and Tailem Bend was introduced in 1977. This resulted in the closure of all signal cabins from Belair to Tailem Bend and big savings in the cost of moving trains. All upper quadrant signals had been replaced by colour light signals in 1987.

Train Services

In 1883 there were two Down and two Up passenger trains daily to and from Aldgate. In 1890 the passenger timetable showed five daily Down trains, plus one mixed, and four daily Up trains, plus two mixed. Commuter services from Belair commenced in 1923, in addition to those running to Aldgate and Bridgewater. In later years commuter services terminated at either Belair or Bridgwater. Bridgewater services were usually handled by 'big power' engines such as 700 and 710 class. The shorter Belair workings usually had four cars and were hauled by F or Rx class engines. The service between Belair and Bridgewater stopped in 1987 and all stations beyond Belair were closed.

I have included two timetables to illustrate services; a 1911 one to illustrate early services, and a 1942 timetable for later services. The 1911 timetable shows the trains through Belair for Monday to Saturday. It was a busy station as there are a significant number of crosses with other trains, including a number of three-way crosses.


The 1942 timetable shows almost twice as many trains with a significant increase in the number of commuter services. There would have been no freight traffic at Belair as there was no goods shed or goods sidings.

In 1995 the gauge standardisation of the line between Melbourne and Adelaide resulted in the double track to Belair becoming two single tracks; one standard gauge and one broad gauge for suburban services. Post standardisation, all commuter trains now terminate at the northernmost platform, renamed Platform 1 as it is the only platform now used by commuter trains.

In 1997, National Rail's locomotive, NR94, was named *Belair*.


Track Plans


The plans, published with this article, started from a tracing of an



Above. In September 1977 AN loco 965, B end leading, leads 953+943+939 on Train No.609, Tailem Bend Mixed through Belair. A camp train is in the yard. Photo: Barry Marshall, NRM Archives 97-1262-d597.

Below. AN-liveried 865 and 853 also lead a freight train out of Belair. Photo: NRM Archives AK23444.







Above. Belair station in 1985. A Red Hen railcar stands in what was then called Platform 3. Photo: NRM Archives pd435_09.

Left. \overline{A} single 3000 class railcar waits at the metro services platform. Note the newly laid gauge convertible concrete sleepers against the old Up platform. The rails are yet to be moved in to standard gauge. Photo: NRM Archives AK13860. Inset. Belair on 7 May 1995 showing the track after the outside rail has been moved in to standard gauge. Photo: Ross Hurley 96/95/14.

SAR Civil Engineer's 1933 plan of Belair yard, drawn at 40' = 1" scale. From that scale origin various other versions, showing Belair at different dates, were drawn. Signalling is though to be accurate for each date, though the various references used— Weekly Notices, books, examination of photos, advice from our Convention signalling experts, etc—did not always agree with each other. The biggest conundrum was the 1933 plan which showed all signals as lower quadrants. Various other sources confirm that upper quadrant signals were installed from 1924. Did the draftsman just trace an earlier version but not update the signals? I would be grateful for any errors found in these plans to be passed back to me via the Convention email address at mrsaconvention@ gmail.com.

References

The Overland Railway, WH Callaghan.

Line Clear, Reece Jennings. Railways in the Adelaide Hills, RSallis. Blood Sweat & Toil, Building the Hills Railway, Flinders University, J Callen. South Australian newspapers on Trove. Wikipedia.

SAR Weekly Notices.

<u>SAR Maintenance Cards</u>, a handwritten log presumably maintained by the Civil Engineer's office, courtesy of the NRM. Each entry is identified by a docket (file) number which usually contains the year in which the docket was created.

SAR Card Indexes, a typed log presumably of drawing numbers maintained by the SAR Drawing Office, courtesy of Refreshing Memories (was Inprotrans). Dates could be determined from some drawing numbers but there were different number series used, many of which had no date identification.

Acknowledgements

National Railway Museum Mitcham Local History Service Coromandel Valley and District National Trust National Library of Australia Trove website for newspaper reports Bill Lewis Des Egan

Timetable, South Line, July 1911

Monday-Saturday: Down

| Day | Туре | Tn No | Departs | Time | То | Notes |
|----------------------------|-------------------------------|-------|------------------|---------|----------------|--|
| Daily | Goods | 1 | Departs Adelaide | 12.15am | Murray Bridge | |
| When nec. | Goods | 3 | Departs Adelaide | 1.30 | Murray Bridge | |
| Daily | Goods | 5 | Departs Adelaide | 2.50 | Murray Bridge | |
| Daily | Goods | 7 | Departs Adelaide | 3.25 | Murray Bridge | |
| Daily | Goods | 9 | Departs Adelaide | 4.00 | Strathalbyn | |
| When nec. | Goods | 11 | Departs Adelaide | 4.55 | Murray Bridge | |
| When nec. | Goods | 15 | Departs Adelaide | 5.20 | Murray Bridge | |
| Daily | Pass | 21 | Departs Adelaide | 6.45 | Murray Bridge | Through Belair 7.28. |
| Daily | Pass | 25 | Departs Adelaide | 7.25 | Victor Harbour | Through Belair 8.08. |
| Mon, Wed, Fri | Goods | 33 | Departs Adelaide | 8.08 | Murray Bridge | At Belair 9.21–9.29. Crosses 20. |
| When nec. | Goods | 37 | Departs Adelaide | 9.18 | Strathalbyn | |
| Sat | Pass, Special Picnic Train | 39 | Departs Adelaide | 10.00 | Belair | Arrives 10.46. (No special return train, cars picked up by another train?) |
| Daily | Pass | 43 | Departs Adelaide | 10.30 | Bridgewater | At Belair 11.13-11.14. Crosses 26. |
| When nec, | Goods | 45 | Departs Adelaide | 11.30 | Murray Bridge | At Belair 12.52–12.54. Crosses 30. |
| When nec, exc. Sat | Goods | 47 | Departs Adelaide | 12.00pm | Mount Barker | At Belair 1.12–1.44. Crosses 36. |
| Sat | Pass | 51 | Departs Adelaide | 1.02 | Bridgewater | At Belair 1.46–1.47. Crosses 36. |
| Sat | Pass | 57 | Departs Adelaide | 1.25 | Mount Barker | Through Belair 2.07. |
| Wed, Sat | Pass | 59 | Departs Adelaide | 2.03 | Bridgewater | At Belair 1.46–1.47. Crosses 40. |
| Sat | Special Express * | _ | Departs Adelaide | 3.12 | Victor Harbour | November to April only. Through Belair 3.48. |
| Daily | Intercolonial Express | 65 | Departs Adelaide | 4.30 | Melbourne | Through Belair 5.09. Crosses 50. |
| Daily | Pass | 69 | Departs Adelaide | 4.48 | Murray Bridge | Through Belair 5.31. |
| Daily | Pass | 73 | Departs Adelaide | 5.25 | Strathalbyn | At Belair 6.09–6.10. Crosses 60. |
| Daily, exc. Sat. | Pass | 83 | Departs Adelaide | 6.25 | Bridgewater | At Belair 7.08–7.10. Crosses 68. |
| Sat | Pass | 87 | Departs Adelaide | 7.30 | Bridgewater | Through Belair 8.13. Crosses 74. |
| Daily exc. Sat | Goods | 91 | Departs Adelaide | 8.50 | Murray Bridge | At Belair 9.55–10.16. Crosses 84, 92. |
| Mon, Tue, Wed, Thu, Fri | Pass | 95 | Departs Adelaide | 10.17 | Aldgate | Through Belair 11.00. |
| Wed, Sat | Pass | 99 | Departs Adelaide | 11.10 | Aldgate | Through Belair 11.53. Crosses 94. |

Sunday: Down

| Day | Туре | Tn No | Departs | Time | То | Notes |
|-----|------|-------|------------------|---------|-------------|-----------------------|
| Sun | Pass | 3 | Departs Adelaide | 10.15am | Bridgewater | Through Belair 10.58. |
| Sun | Pass | ЗA | Departs Adelaide | 10.45 | Bridgewater | Through Belair 11.29. |
| Sun | Pass | 9 | Departs Adelaide | 2.20pm | Bridgewater | Through Belair 3.03. |
| Sun | Pass | 13 | Departs Adelaide | 6.30 | Bridgewater | Through Belair 7.13. |

Monday–Saturday: Up

| Day | Туре | Tn No | Departs | Time | То | Notes |
|-------|-------------------|-------|--------------------------|------|----------|--|
| Daily | Pass | 8 | Departs Aldgate | 6.49 | Adelaide | Through Belair 7.14. |
| Daily | Pass | 14 | Departs Murray Bridge | 5.30 | Adelaide | Through Belair 8.09. Crosses 25. |
| Mon | Special Express * | _ | Dep Victor Harbour | 7.05 | | November to April only. Through Belair 9.35. Crosses 35. |
| Daily | Pass | 18 | Departs Strathalbyn | # | Adelaide | Through Belair 9.03. |

Modelling the Railways of South Australia - 2020

| Day | Туре | Tn No | Departs | Time | То | Notes |
|-----------------------------|-----------------------------|-------|--|---------|----------|---|
| Daily exc. Mon | Intercolonial Express | 20 | Departs Melbourne | | Adelaide | Through Belair 9.22 am. Crosses 33. May stop at Belair for Vic passengers to alight. |
| When nec. | Goods | 24 | Departs Mount Barker | 8.34 am | Adelaide | Through Belair 8.27. Crosses 37. |
| Sat | Engine & empty pass cars | 26 | Departs Belair | 11.15 | Adelaide | Engine of 39 Down with any pass cars not required for Up train. Crosses 43. |
| Daily | Pass | 30 | Departs Aldgate | 12.18pm | Adelaide | Return of 43 Down. Through Belain at 12.52. Crosses 45. |
| When nec. | Goods | 36 | Departs Murray Bridge | 9.52am | Adelaide | Through Belair 1.44pm. Crosses 47, 51. |
| When nec. | Goods | 40 | Departs Murray Bridge | 10.40 | Adelaide | Through Belair 2.49. Crosses 59. |
| When nec., exc. Wed, Sat | Goods | 42 | Departs Murray Bridge | 11.24 | Adelaide | At Belair 3.10–3.22. |
| When nec., exc. Sat | Goods | 46 | Departs Murray Bridge | 12.11pm | Adelaide | Through Belair 4.07. |
| Wed, Sat | Pass | 50 | Departs Aldgate | 4.35 | Adelaide | At Belair 5.08–5.13. Crosses 65. Return of 59 Down. |
| When nec. | Goods | 58 | Departs Murray Bridge | 1.05 | Adelaide | Through Belair 4.45. |
| Daily | Pass | 60 | Departs Victor Harbour | # | Adelaide | Through Belair 6.08. Crosses 73. |
| When nec., exc. Sat | Goods | 64 | Departs Murray Bridge | 2.00 | Adelaide | |
| Sat | Pass | 66 | Departs Bridgewater | 6.15 | Adelaide | Return of 51 Down. |
| Daily | Pass | 68 | Departs Murray Bridge | 4.45 | Adelaide | Through Belair 7.10. Crosses 83. |
| When nec. | Goods | 72 | Departs Murray Bridge | 2.50 | Adelaide | Through Belair 7.51. |
| Daily | Goods | 74 | Departs Strathalbyn | # | Adelaide | Through Belair 8.12. Crosses 87. |
| Daily exc. Wed | Pass | 78 | Departs Mount Barker Bridgewater | # | Adelaide | Through Belair 8.51. Return of 57 Down on Saturdays from Moun Barker and 83 Down on other days from Bridgewater. Sat only from Bridgewater. |
| Daily | Goods | 82 | Departs Murray Bridge | 3.50 | Adelaide | Through Belair 9.15. |
| Wed, Sat | Pass | 84 | Departs Aldgate | 9.20 | Adelaide | Through Belair 9.55. Crosses 91 Return of 83 Down Wed and 87 Down Sat. |
| Daily | Goods | 88 | Departs Murray Bridge | 5.10 | Adelaide | Through Belair 9.35. |
| Daily | Goods | 92 | Departs Murray Bridge | 6.15 | Adelaide | Through Belair 10.16. Crosses 91 |
| When nec. | Goods | 94 | Departs Murray Bridge | 7.10 | Adelaide | At Belair 11.42–11.53. Crosses 99 |
| When nec. | Goods | 96 | Departs Murray Bridge | 8.12 | Adelaide | Through Belair 12.36 am. |
| When nec. | Goods | 98 | Departs Murray Bridge | 8.45 | Adelaide | At Belair 12.56-1.05. |
| When nec. | Goods | 100 | Departs Murray Bridge | 9.35 | Adelaide | At Belair 1.17-1.26. Crosses 1. |
| When nec. | Goods | 102 | Departs Murray Bridge | 10.05 | Adelaide | Through Belair 2.36. Crosses 3. |
| When nec. | Goods | 104 | Departs Murray Bridge | 10.40 | Adelaide | Through Belair 3.28. |

No information in timetable.

Timetable, South Line, March 1942

Monday–Friday: Down

| Day | Туре | Tn No | Departs | Time | То | Notes |
|-----------------|------------------------------|-------|------------------|---------|---------------------------|--|
| Mon, Wed, Fri | Freight | 71 | Departs Mile End | 12.30am | Victor Harbour | |
| Thu | Freight | 145 | Departs Mile End | 2.50 | Mt Pleasant | |
| Mon | Express Pass to Aldgate | 107 | Departs Adelaide | 3.30am | Bridgewater | Through Belair 4.05. |
| Thu | Freight | 201 | Departs Mile End | 4.45 | Sedan | |
| Daily | Pass | 147 | Departs Adelaide | 4.55 | Belair | Arrives 5.48. Works back as 110 |
| Daily | Pass | 195 | Departs Adelaide | 6.21 | Belair | Arrives 7.16. Works back as 188 |
| Daily | Pass | 217 | Departs Adelaide | 6.50 | Belair | Arrives 7.43. Works back as 216 |
| Daily | Pass | 231 | Departs Adelaide | 7.10 | South-East and Barmera | At Belair 7.49. |
| Daily | Pass | 251 | Departs Adelaide | 7.32 | Pinnaroo | AtBelair 8.10. Picks up passengers for stations beyond Bridgewater. Crosses 218. |
| Daily | Pass | 257 | Departs Adelaide | 7.38 | Belair | Arrives 8.33. Works back as 258. |
| Daily | Pass | 291 | Departs Adelaide | 8.10 | Belair | Arrives 9.05. Works back as 282. |
| Daily | Pass | 331 | Departs Adelaide | 8.52 | Bridgewater | At Belair 9.45. |
| Fri | Pass | 403 | Departs Adelaide | 10.05 | Victor Harbour | At Belair 10.45. |
| Daily | Pass | 423 | Departs Adelaide | 10.45 | Bridgewater | At Belair 11.35. |
| Daily | Pass | 547 | Departs Adelaide | 1.04pm | Belair | Arrives 1.59. Works back as 550. |
| Daily | Pass | 613 | Departs Adelaide | 2.15 | Bridgewater | At Belair 3.05. |
| Mon | Freight | 643 | Departs Mile End | 2.30 | Sedan | |
| Mon–Thu | Freight | 669 | Departs Mile End | 2.45 | Tailem Bend | |
| Daily | Pass | 679 | Departs Adelaide | 3.47 | Bridgewater | At Belair 4.21. |
| Mon–Thu | Pass | 705 | Departs Adelaide | 4.30 | Tailem Bend | At Belair 5.11. |
| Daily | Pass | 713 | Departs Adelaide | 4.42 | Belair | Arrives 5.37. Works back as 732. |
| Mon–Thu, Fri | Pass Motor Pass | 723 | Departs Adelaide | 4.58 | Mt Pleasant | At Belair 5.41. |
| Daily | Pass | 729 | Departs Adelaide | 5.05 | Belair | Arrives 6.04. Works back as 736. |
| Daily | Pass | 753 | Departs Adelaide | 5.25 | Bridgewater | At Belair 5.59. 700 class engine. |
| Daily | Pass | 755 | Departs Adelaide | 5.26 | Belair | Arrives 6.18. Works back as 764. |
| Daily | Pass | 775 | Departs Adelaide | 5.45 | Bridgewater | At Belair 6.22. |
| Daily | Pass | 777 | Departs Adelaide | 5.45 | Belair | Arrives 6.38. Works back as 780. Superheated Rx class engine. |
| Daily | Pass | 795 | Departs Adelaide | 6.05 | Victor Harbour | At Belair 6.40. |
| Daily | Pass | 811 | Departs Adelaide | 6.20 | Bridgewater | At Belair 7.14. |
| Mon–Thu | Freight | 819 | Departs Mile End | 6.30 | Tailem Bend | |
| Daily | Overland Pass | 837 | Departs Adelaide | 7.00 | Melbourne | Through Belair 7.39. |
| Fri | Pass | 845 | Departs Adelaide | 7.15 | Tailem Bend | Through Belair 7.49. Does not stop before Long Gully. |
| Tue & Thu | Pass | 857 | Departs Adelaide | 7.30 | South-East | Through Belair 8.09. Stop if required to pick up passengers booked for beyond Tailem Bend. |
| Mon–Thu Fri | Pass Motor & Trailer Pass | 873 | Departs Adelaide | 8.00 | Tailem Bend | Arrives 8.30. Works back as 902. |
| When nec. | Overland Pass | 881 | Departs Adelaide | 8.00 | Melbourne | Through Belair 8.38. |
| Daily | Freight | 873 | Departs Mile End | 8.00 | Tailem Bend | |
| Daily | Pass | 887 | Departs Adelaide | 8.10 | Bridgewater | At Belair 9.05. |
| Mon-Thu | Interstate Fast Freight | 893 | Departs Mile End | 8.40 | Melbourne | Arrives Tailem Bend 1.35am next day. |
| Daily | Pass | 925 | Departs Adelaide | 9.38 | Bridgewater | At Belair 10.23. Superheated Ry class engine. |
| Daily | Freight | 933 | Departs Mile End | 9.45 | Tailem Bend | Tue-Fri formed by 888 ex Pt Adelaide and leaves from Mile End Jct. |
| Tue–Fri | Freight | 939 | Departs Mile End | 10.00 | Tailem Bend | |

Modelling the Railways of South Australia - 2020

Monday-Saturday: Down cont.

| Day | Туре | Tn No | Departs | Time | То | Notes |
|---------|------------|-------|------------------|---------|-------------|--|
| Mon | Freight | 947 | Departs Mile End | 10.15 | Mt Pleasant | |
| Daily | Pass Motor | 959 | Departs Adelaide | 10.45 | Bridgewater | At Belair 11.34. |
| Mon | Freight | 961 | Departs Mile End | 10.50 | Tailem Bend | |
| Daily | Pass | 979 | Departs Adelaide | 11.32 | Bridgewater | At Belair 12.04am. |
| Daily | Freight | 991 | Departs Mile End | 11.45 | Tailem Bend | |
| Tue-Sat | Pass | 31 | Departs Adelaide | 12.50am | Bridgewater | At Belair 1.37. May run ahead of scheduled time if section ahead is clear. |

From the 1937 WTT, wayside running times from Mile End to Belair for freight trains were:


- 500 class......55 minutes
- 700, 710, 720 classes......60 minutes
- Rx, 600, 620 classes (full loading).....61 minutes



Left. The interior of the signal cabin in 1974. The cabin was destroyed by fire in 2002. The Friends of Belair Station group had the building completely rebuilt. The building was built by students from TAFE's Marleston campus, and the lever frame was painstakingly restored over several years by a member of the Friends group. Along with donated equipment the interior is now virtually the same as in this photo. It complements an historic display of signals and other equipment behind the station.Photo: Peter Fehlberg.

Below. 747 blowing lots of steam rounds the bend at the Adelaide end of Belair station as it pulls into Platform 2. Photo: NRM Archives AK23751.

2 PLAT



Monday-Friday: Up

| Day | Туре | Tn No | Departs arts | Time | То | Notes |
|----------------|----------------------------|----------|---|---------|--|--|
| Daily | Freight | 890 | Departs Tailem Bend | 8.00 | Arrive Mile End 12.30am | |
| Daily | Freight | 838 | Departs Tailem Bend | 6.25 | Arrive Mile End 12.36 | |
| Tue | Freight | 854 | Departs Mt Pleasant | | Arrive Mile End 2.04 | |
| Daily | Freight | 948 | Departs Tailem Bend | 9.10 | Arrive Mile End 4.53 | |
| Wed-Sat | Interstate Fast Freight | 900 | Departs Melburne | | Arrive Mile End 5.07 | Leaves Tailem Bend 11.45pm previous day. Arrives Mile End 5.07 |
| Mon | Freight | 68 | Departs Tailem Bend | 12.04am | Arrive Mile End 5.10 | |
| Wed | Livestock | 64 | Departs Tailem Bend | 1.05 | Mile End 5.56, thence to Dry Creek | |
| # | Pass | 92 | Departs Bridgewater | 5.07 | Adelaide | At Belair 5.38. |
| When nec. | Freight | 460 | Departs Tailem Bend | 12.00pm | Arrive Mile End 6.20 | |
| # | Pass | 110 | Departs Belair | 5.57 | Adelaide | |
| Daily | Pass | 118 | Departs Bridgewater | 5.39 | Adelaide | At Belair 6.17. Superheated Rx class engine. |
| Daily | Pass | 146 | Departs Bridgewater | 6.10 | Adelaide | At Belair 6.47. |
| Daily | Pass | 164 | Departs Bridgewater | 6.46 | Adelaide | At Belair 7.21. Superheated Rx class engine. |
| Daily | Pass | 188 | Departs Belair | 7.29 | Adelaide | |
| Daily | Pass | 216 | Departs Belair | 7.55 | Adelaide | |
| Daily | Pass | 218 | Departs Bridgewater | 7.34 | Adelaide | Through Belair about 8.10. Does not stop. |
| Daily | Overland Pass | 240 | Through Bridgewater | 7.56 | Adelaide | Through Belair 8.27. Does not stop. |
| Daily | Pass | 258 | Departs Belair | 8.39 | Adelaide | |
| Mon, Wed, | Pass | 260 | Departs Bridgewater | 8.26 | Adelaide | Through Belair 9.00. Stop when |
| Fri | F d 55 | 200 | Departs Bridgewater | 0.20 | Adelaide | necessary for passengers to alight only. |
| Tue, Thu | Pass | 262 | Departs South-East | | Adelaide | Through Belair 9.00. Stop when necessary for passengers to alight only. |
| Daily | Pass Motor | 276 | Departs Mt Pleasant | | Adelaide | Through Belair 9.20. Stop when necessary for passengers to alight only. |
| Daily | Pass | 286 | Departs Belair | 9.27 | Adelaide | |
| If required | Overland Pass | 290 | Through Bridgewater | 9.09 | Adelaide | Through Belair 9.41. Crosses 331. |
| Tue, Thu | Pass | 302 | Departs Tailem Bend | | Adelaide | Through Belair 10.07. Stop when necessary for passengers to alight |
| E ei | Freicht | 754 | Departs Mt Discourt | | Anni ve Mile Engl | only. |
| Fri | Freight | 754 | Departs Mt Pleasant | E 00 | Arrive Mile End Arrive Mile End 10.56 | |
| Tue | Freight | 766 | Departs Tailem Bend | 5.00 | | At Doloir 11 04 |
| Daily Daily | Pass | 346 | Departs Bridgewater Departs Victor Harbour | 10.52 | Adelaide | At Belair 11.24. Through Belair 11.57. Stop when necessary for passengers to alight only. |
| Tue & Thu | Freight | 674 | Departs Strathalbyn | | Arrive Mile End 1.18. | |
| Daily | Pass | 454 | Departs Bridgewater | 1.08pm | Adelaide | At Belair 1.38pm. Superheated Rx class engine. |
| Daily | Pass | 456 | Departs Pinnaroo | | Adelaide | Through Belair 1.54. Stop when necessary for passengers to alight only. |
| Mon-Thu Fri | Pass Motor | 470 | Departs Mount Barker Departs Bridgewater | 1.29 | Adelaide | Through Belair 2.05. |
| Bridgewater | 1.29 | Adelaide | At Belair 2.05. | | | |
| Mon | Freight | 643 | Departs Mile End | 2.30 | Sedan | |
| Daily | Pass | 550 | Departs Belair | 3.34 | Adelaide | |
| Daily | Pass | 656 | Departs Bridgewater | 4.16 | Adelaide | At Belair 4.50. |
| Daily | Pass | 732 | Departs Belair | 5.53 | Adelaide | |
| Daily | Empty Pass | 736 | Departs Belair | 6.14 | Mile End | Detaches cars at Eden and works freight 736. |
| Daily | Pass | 764 | Departs Belair | 6.28 | Adelaide | |
| Daily | Pass | 780 | Departs Belair | 6.50 | Adelaide | Superheated Rx class engine. |
| Daily | Pass | 786 | Departs Bridgewater | 6.21 | Adelaide | At Belair 6.59. Superheated Ry class engine. |

Monday-Friday: Up cont.

| Day | Туре | Tn No | Departs arts | Time | То | Notes |
|-------|------------|-------|---------------------|-------|----------|--|
| Daily | Pass | 802 | Departs South-East | | Adelaide | Through Belair 7.34. Stop when necessary for passengers to alight only. Crosses 837. |
| Fri | Pass | 848 | Departs Bridgewater | 7.38 | Adelaide | Through Belair 8.18. Stop when necessary for passengers to alight only. |
| Daily | Pass Motor | 902 | Departs Belair | 9.34 | Adelaide | |
| Daily | Pass | 912 | Departs Bridgewater | 9.15 | Adelaide | At Belair 9.48. |
| Daily | Pass Motor | 934 | Departs Bridgewater | 10.05 | Adelaide | At Belair 10.41. |

No information in timetable.


From the 1937 WTT, wayside running times from Tailem Bend to Belair for freight trains were:

- 500 class......214 minutes
- 700, 710, 720 classes......231 minutes
- Rx, 600, 620 classes (full loading).....250 minutes




Left. A 720 class hauls a rake of O wagons loaded with what looks like coal through Belair. Photo: NRM Archives AK14563.

Right. In 1985 V/Line's X49, S301 and a Cclass loco haul TNT loading on an intermodal train around Fosters Corner, heading towards Belair. The colour light signals will indicate whether it will enter the main line or loop. Photo: NRM Archives 14-218-3677.



Modelling the Railways of South Australia - 2020






These two photos show the bridges that have existed at each end of Belair yard almost since the beginning. This photo shows the Upper Sturt Road bridge over the tracks at the Adelaide end of Belair station in 1983. Photo: STA, NRM Archives 5-98-sc0631.




This is the bridge at the Mount Lofty end of Belair leading into National Park in 1983, with the colour light Up Home gantry signal in front of the bridge. Photo: STA, NRM Archives 5-98-sc0634. Both photos are looking towards the station yard.






Track diagram of 1912, one of a series of station diagrams drawn for the SAR in 1912-13..


The following plans are based on tracings of the SAR 40' to 1" plan produced by the Chief Engineer in 1933, and are drawn to scale. All drawings by the author.





Signal cabin diagram as at 1977 when the cabin closed.

Upper Sturt Ro



Modelling the Railways of South Australia - 2020